





Hydraulics

420 Mobile Piston Pump
Model Codes


ADU041
ADU049
ADU062
ADU080



420 Mobile Piston Pump Model Codes





The following 32 digit coding system has been developed to identify standard configuration options for the 420 Series Variable Displacement Pump. Use this code to specify a pump with the desired features. All 32-digits of the code must be present to release a new product number for ordering.



** Standard/Preferred Configurations

420 Mobile Piston Pump Model Codes



** Standard/Preferred Configurations

Model Code	Assembly #
ADU041R02AA10A43140000100100CD0A	421AK00246A
ADU041R05AA10A43140000100100CD0A	421AK00248A
ADU041R08AA10A43140000100100CD0A	421AK00250A
ADU041R02AE10C43000000100100CD0A	421AK00031A
ADU041R02AE10C28000000100100CD0A	421AK00230A
ADU041R05AE10A43140000100100CD0A	421AK00032A
ADU041R34AE10A43140000100100CD0A	421AK00318A
ADU049L02AA10C43000000100100CD0A	421AK00049A
ADU049R02AA10C43000000100100CD0A	421AK00017A
ADU049R05AA10C28000000100100CD0A	421AK00095A
ADU049L08AA10A28140000100100CD0A	421AK00182A
ADU049R05AA10A43140000100100CD0A	421AK00029A
ADU049R08AA10A28140000100100CD0A	421AK00183A
ADU049R32AA10A43140000100500CD0A	421AK00340A
ADU049R33AA10A43140000100500CD0A	421AK00346A
ADU049R34AA10A43140000100100CD0A	421AK00315A
ADU049L05AE10A43140000100100CD0A	421AK00411A
ADU049R05AE10A43140000100100CD0A	421AK00019A
ADU062L02AA10C43000000100100CD0A	421AK00050A
ADU062L08AA10C43000000100100CD0A	421AK00585A
ADU062R01AA10C43000000100100CD0A	421AK00072A
ADU062R02AA10C43000000100100CD0A	421AK00016A
ADU062R05AA10C28000000100100CD0A	421AK00578A
ADU062R08AA10C28000000100100CD0A	421AK00040A
ADU062L05AA10A43140000100100CD0A	421AK00118A
ADU062R05AA10A43140000100100CD0A	421AK00018A
ADU062R05AA10A28140000100100CD0A	421AK00302A
ADU062R08AA10A28140000100100CD0A	421AK00110A
ADU062R32AA10A43140000100500CD0A	421AK00326A
ADU062R33AA10A43140000100500CD0A	421AK00332A
ADU062R34AA10A43140000100100CD0A	421AK00312A
ADU080R05AA10C28000000100100CD0A	421AK00641A
ADU080L32AA10A28140000100500CD0A	421AK00448A
ADU080L32AB10A271400002AC500CD0A	421AK00538A
ADU080L32AB10A2714000A2AC500CD0A	421AK00539A
ADU080L33AB10A271400002AC500CD0A	421AK00536A
ADU080L33AB10A2714000A2AC500CD0A	421AK00537A
ADU080R32AB10A271400002AC500CD0A	421AK00542A
ADU080R32AB10A2714000A2AC500CD0A	421AK00543A
ADU080R33AB10A271400002AC500CD0A	421AK00540A
ADU080R33AB10A2714000A2AC500CD0A	421AK00541A

Eaton
 14615 Lone Oak Road
 Eden Prairie, MN, 55344
 USA
 Tel: 952 937-9800
 Fax: 952 974-7722
 www.hydraulics.eaton.com

Eaton
 20 Rosamond Road
 Footscray
 Victoria 3011
 Australia
 Tel: (61) 3 9319 8222
 Fax: (61) 3 9318 5714

Eaton
 Dr.-Reckeweg-Str. 1
 D-76532 Baden-Baden
 Germany
 Tel: (49) 7221 682-0
 Fax: (49) 7221 682-788